

# GraviProbe 2.0 repair guide

## How to open the GraviProbe 2.0

30 juli 2019

---

**Auteur** Kevin Dedeyne

---

**Revisor**

---

<b>Revisie nr.</b>	<b>Datum</b>	<b>Beschrijving</b>
--------------------	--------------	---------------------

---

1.	02/08/2018	Initial draft
----	------------	---------------



## Summary

Summary .....	2
Introduction .....	3
Method .....	3
1. Remove white cap.....	3
2. Remove second white cap .....	4
3. Dismantle top part GraviProbe .....	5
4. Dismantle bottom part GraviProbe.....	6
5. Reassemble GraviProbe .....	6



## Introduction

This is a guide that describes on how to fix a disconnected sensor cable when the GraviProbe is flashing red upon usage.

## Method

### 1. Remove white cap

Remove the first white cap by turning it to the left until it is dismounted.





## 2. Remove second white cap

Place the included extension with the two ends down on top of the GraviProbe and turn to the left until the second white caps comes off.







### 3. Dismantle top part GraviProbe

Now turn the included extension around and screw it a little bit to the right so that it is tightened. Now hold the bottom part of the GraviProbe between your legs and carefully pull the upper part up so that the battery connector comes loose.





## 4. Dismantle bottom part GraviProbe

Pull out the battery compartment and put it away for a second. It is now possible to screw the other side of the GraviProbe loose. Turn it to the left.



## 5. Reassemble GraviProbe

To reassemble the GraviProbe just repeat steps 1 to 4 in reverse order.